


COLUMN CONNECTIONS



SIZE OF COLUMN SHOES AND ANCHOR BOLTS AS PER DESIGN REQUIREMENTS

ALL DIMENSIONS ARE IN MILLIMETRES (mm) UNLESS OTHERWISE STATED